HART UNIVERSAL TEMPERATURE TRANSMITTER

SEM310 / SEM310X

| > | HART 5,6,7 COMPATABLE |
|---|---|
| > | UNIVERSAL INPUT, DUAL CHANNEL |
| > | ATEX & IEC Ex Version |
| > | MATHS FUNCTIONS |
| > | SENSOR CHARACTERISTICS DOWNLOAD VIA USB PORT ALLOWS FOR CUSTOM TYPES |
| > | FLASH TESTED TO 4 KV DC |
| | |



INTRODUCTION

The SEM310 is a HART 5,6, or 7 compatible universal transmitter. It accepts RTD, Thermocouple, Potentiometer or millivolt input signals and converts them to the industry standard (4 to 20) mA transmission signal. Alternatively HART multidrop mode can be selected.

The SEM310 is programmed using a standard USB lead. The ATEX / IECEx version (SEM310X) is programmed with a ATEX / IECEx approved communication lead (USBX Config).

Both versions use our free configuration USBSpeedlink software downloaded from our web site. Standard features can also be programmed using HART communication.



Some of the enhanced SEM310 features are as follows;

SENSOR REFERENCING

The SEM310 sensor referencing via the Windows based USBSpeedlink software allows for close matching to a known reference sensor eliminating possible sensor errors.

USER CALIBRATION

In addition to sensor referencing, user offset and current output trimming is possible via the USB and HART commands.

CUSTOM LINEARISATION

The SEM310 can be programmed with a custom linearization to suit nonstandard sensors or sensors with unusual or unique characteristics. Consult the sales office for details.

SENSOR BURN OUT DETECTION

If a sensor wire is broken or becomes disconnected the SEM310 output will automatically go to its user defined level (upscale or downscale) or pre-set value.

OUTPUT CURRENT PRESET

For ease of system calibration and commissioning the output can be set to a pre-defined level anywhere within the (4 to 20) mA range.

Hart® Registered trademark of the HART Communication Foundation.





ELECTRICAL INPUT

| Range + Options | Accuracy | Stability |
|---------------------------------------|---------------------------------------|-----------------------------|
| Resistance | | |
| (10 to 10000) Ω | (10 to 500) Ω ± 0.055 Ω, | (0 to 500) Ω 0.013 Ω/°C, |
| Excitation 200 uA | (500 to 2500) Ω ± 0.5 Ω, | (500 to 2500) Ω 0.063 Ω/°C, |
| Lead resistance (0 to 20) Ω | (2500 to 10500) Ω ±0.15 % of reading | (2500 to 10500) Ω 0.27 Ω/°C |
| (2,3 or 4 Wire connection) | (+ Lead error on 2 wire) | |
| Slide Wire | | |
| (0 to 100) % Travel | ±0.1 % | ±0.001%/°C |
| Wire resistance (1 to 100) K Ω | | |
| mV | · · · · · · · · · · · · · · · · · · · | |
| (-205 to 205) mV DC | ±0.02 mV | ±0.005 mV/°C |
| (-1000 to 1000) mV DC | ±10.0 mV | ±0.02 mV/°C |

SENSOR INPUT

RTD (Single/ 2 wire Dual Channel; isolated tip only for Dual operation)

| Туре | Range | Accuracy/Stability |
|-------------------------------|------------------------------|-----------------------------|
| Pt100 (IEC) | (-200 to 850) °C | 0.2°C ± (°0.05% of reading) |
| Pt500 (IEC) | (-200 to 750) °C | (Plus sensor) |
| Pt1000 (IEC) | (-200 to 600) °C | |
| Ni100 | (-60 to 180) °C | |
| Ni120 | (-80 to 260) °C | |
| Ni1000 | (-60 to 180) °C | |
| Cu53 | (-50 to 180) °C | |
| Cu100 | (-80 to 260) °C | |
| Cu1000 | (-80 to 260) °C | |
| Library more (standards/types | s) Including silicon sensors | |

Thermocouple (Single/Dual Channel; isolated tip only for Dual operation)

| Туре | Range | Accuracy/Stability |
|---|-------------------|--|
| К | (-200 to 1370) °C | ±0.1 % of full scale ± 0.5 °C |
| J | (-100 to 1200) °C | (Plus sensor Error) |
| N | (-200 to 1300) °C | |
| E | (-200 to 1000) °C | |
| Т | (-200 to 400) °C | ±0.2 % of full scale ± 0.5 °C (Plus sensor Error) |
| R | (0 to 1760) °C | ±0.1 % of full scale ± 0.5 °C |
| S | (0 to 1760) °C | over range (800 to 1760) °C (Plus sensor Error) |
| L | (-100 to 600) °C | ±0.1 % of full scale ± 0.5 °C |
| U | (0 to 600) °C | (Plus sensor Error) |
| В | (-200 to 1300) °C | |
| С | (0 to 2300) °C | |
| D | (0 to 2300) °C | |
| G | 0 to 2300) °C | |
| Library contains more (standards/types) | | |

DUAL CHANNEL OPERATION

| Thermocouples A & B | Functions; Average, Redundancy, A + B, A - B, Highest, Lowest |
|---------------------|--|
| mVA&B | Functions; Average, A + B, A - B, Highest, Lowest |
| RTD A & B | Two wire connection. Functions; Average, A + B, A - B, Highest, Lowest |



AMBIENT SENSOR (Cold Junction)

| Туре | Range | Accuracy/Stability |
|--------------------------|----------------|---------------------|
| Thermistor 10K Beta 3380 | (-40 to 85) °C | ±0.2 °C ±0.05 °C/°C |

OUTPUT

| Type\options | Range | Accuracy/Stability/Notes |
|--------------------------|--------------------------------|--------------------------------|
| Two wire current | (4 to 20) mA | (mA Out/ 2000) or 5 uA |
| | | whichever is the greater, |
| | | Drift 1 uA/°C |
| User set minimum current | (3.5 to 4.0) mA 3.8 mA default | |
| User set maximum current | (20 to 23.0) mA | |
| | 20.5 mA default | |
| User set error current | (3.5 to 23.0) mA | |
| User Pre-set current | (20 to 23.0) mA | For diagnostics |
| Current loop off | 3.5 mA | Hart multi-drop communications |
| Loop effect | ± 0.2 uA/V | |
| Loop supply | 10 to 30 V DC | SELV |
| Max load | [(V supply – 10)/20) K Ω | 700 Ω @ 24 V DC |
| Protection | Reverse and over voltage | |

USB USER INTERFACE

Approved USB configuration lead required for SEM310X

| Type\options\function | Description | Notes |
|------------------------|-------------------------------------|---------------------------------------|
| USB 2.0 | Mini B USB | USB powers device for config |
| | Approved configuration lead SEM310X | Only. Power loop for live data. |
| Baud Rate | 38,400 | |
| Sensor configuration | Sensor type | TC/mV/RTD/Ohms/Slide wire |
| | | Dual TC/mV/RTD |
| | Sensor offset | Dual use separate offsets |
| | Sensor fail high or low | Dual Share sensor fail |
| | Pre-set sensor value | For diagnostics |
| | Set damping | |
| | Set No. wires resistance Input | 2, 3 or 4 wire |
| | Set fixed or auto cold junction | |
| Profiler configuration | Set profiler input range | In sensor units |
| | Set profiler segments | (4 to 22) segments |
| | Enter profile X~Y values | |
| | Set profiler output units | |
| | Set the output process range | |
| | TC & RTD input only set units | Profiler set up |
| | | |
| | | |
| Output signal | Select the process range for re- | |
| | transmission | Set in profiler out units |
| | Set minimum current | (3.5 to 4.0) mA |
| | Set maximum current | (20 to 23.0) mA |
| | Set the error current | (3.5 to 23.0) mA |
| | Trim 4.0 mA signal | (3.8 to 4.5) mA |
| | Trim 20 mA signal | (19.5 to 20.5) mA |
| | Pre-set Loop current | |
| | Turn loop current off | 3.5 mA |
| Damping | User set PV damping | 1 to 32 seconds to reach 70% of final |
| | | value |
| | | |



USB USER INTERFACE Continued

| Type\options\function | Description | Notes |
|-----------------------------|--|-------|
| HART information | Read/write tag number | 10103 |
| TART Information | Read/write tag date | |
| | Set polling address | |
| | Read/write description | |
| | Read/write message | |
| | Read/write final assembly number | |
| | Read/write long tag | |
| | Read and set RTC | |
| | Read HART version | |
| | | |
| HART specification | Read manufacturers ID | |
| | Read short ID | |
| | Read HART revision | |
| | Read device revision | |
| | Read software revision Read hardware revision | |
| | | |
| | Read unique ID Read No. pre-ambles | |
| | Read maximum No. variables | |
| | Read No. of configuration changes | |
| | Extended device status | |
| | Extended manufacturers ID | |
| | Extended distributes ID | |
| | Device profile | |
| | Device ID1, ID2 & ID3 | |
| Type\Function\options | 1.Read primary variable (PV) | |
| | 2.Read loop current and percentage of | |
| Description | range | |
| | 3.Read dynamic variables and Loop | |
| Туре | current | |
| | 7.Read loop configuration | |
| HART Protocol 1200 baud FSK | 8.Read dynamic variable | |
| Venier | classifications | |
| Version | 9.Read device variables with status | |
| Hart 5 to 7 compatible | 12.Read message | |
| Hart 5 to 7 compatible | 13.Read tag, descriptor and date | |
| Universal commands | 14.Read primary variable transducer | |
| onversar commands | Information | |
| | 15.Read device information | |
| | 16.Read final assembly number | |
| | 17.Write message | |
| | 18. Write tag, descriptor and date | |
| | 19.Write final assembly number | |
| | 20.Read long tag | |
| | 22.Write long tag 38.Reset configuration changed flag | |
| | 48.Read additional device status | |
| | יט.אבמט מטטונוטוומו טבעונצ גומוטג | |
| Additional universal | 0. Read unique ID | |
| commands | 6. Write polling address | |
| | 11. Read unique ID associated with tag | |
| | 21. Read unique ID associated with | |
| | long tag | |
| | | |
| Common practice | 34. Write PV damping value | |
| commands | 35. Write PV range | |
| | 40. Enter/exit fixed current mode | |
| | 41. Perform self-test | |
| | 42. Perform device reset | |
| | 44. Write PV units | |
| | 45. Trim loop current zero | |
| | 46. Trim loop current gain | |
| | 49. Write primary variable transducer | |
| | serial number | |
| | 71. Lock device | |
| | 76. Read lock device state | |
| | | |
| | | |



HART UNIVERSAL TEMPERATURE TRANSMITTER

| Type\options\function | Description | Notes |
|-----------------------|-----------------------------------|--------------------------------------|
| Diagnostics | Read (PV, mA, ambient °C, error & | Up to 150 points |
| | power off) logs points back from | |
| | device | Log Rate (1 to 60) readings per hour |
| | Set the log period | |
| | Clear log and start new log | |
| | Export log data | |
| | Detect open circuit sensor wire | |
| | Cal date, certificate number, | |
| | calibrated by | |
| Live Data | Read sensor signal | |
| | Read profiler input signal | |
| | Read profiler output signal | |
| | Read ambient temperature | |
| | Read % output | |
| | Read mA output | |

GENERAL Function

Description

Isolation Reading update Response time Warm up Start-up time Flash tested 5 Seconds 4 KV DC, working voltage 50 V AC 200 ms 500 ms to reach 70% final value 2 minutes 5 seconds

AMBIENT

Function Temperature Humidity Protection Description Operating/Storage (-40 to 85) °C Operating/Storage (10 to 95) % Non-condensing >= IP65

CONNECTIONS


| Output | Screw terminals (1 to 2) |
|--------|--|
| Input | Screw terminals (3 to 6) |
| USB | Mini USB for SEM310, approved configuration lead for SEM310X |

APPROVALS

EMC ATEX IECEx BS EN 61326 Industrial Ex ia IIC T4 Ga Ex ia IIIC T135 Da Ex ia T4 Ga Ex ia IIIC T135 Da

MECHANICAL

Enclosure Material Dimensions Weight Fixing centres Centre hole Colour DIN standard size terminal block ABS flammability UL94-VO 44 mm diameter 24 mm height Approximately 43 g 33 mm 6.3 mm Black SEM310, Blue SEM310X



Status Instruments Ltd Status Business Park Gannaway Lane, Tewkesbury Gloucestershire, UK GL20 8FD Tel: +44 (0)1684 296818 Fax: +44 (0)1684 293746 Email: sales@status.co.uk Website: www.status.co.uk D2579-01-02 SEM310/310X Data Sheet

